



Measuring your opening for a swing door Single Swing



Track and operator clearance area

Measuring your opening for a swing door Bi-parting or Center Parting



If you are replacing an existing door remember - always measure the opening and not the door

Measure the height of your opening at each side

Now measure the width of the opening at the top, middle and bottom to make sure that the opening width is constant.

Then, choose a left or right side hinge from what you consider to be the front of the door.

Close this window.